



Install jumpers as shown to place the signal from the transceiver to the IsoCat on the ring and the data signals from the IsoCat to the transceiver on the tip. Ground remains the same. Wire the opposite end of the cable to the appropriate pins on the connector required by your transceiver.